

Thank you for choosing CYmodel
Global : www.cymodel.com
Australia : www.austars-model.com
Italia : www.biellaexpress.com

F4U CORSAIR

Item Nr: CY8018



Instruction Manual

Before commencing assembly, please read these instructions thoroughly.

ALMOST - READY - TO - FLY



SAFETY PRECAUTIONS

This radio control model is not a toy!


- First-time builders should seek advice from people having building experience in order to assemble the model correctly and to produce its performance to full extent.
- Assemble this kit only in places out of children's reach!
- Take enough safety precautions prior to operating this model.
You are responsible for this model's assembly and safe operation!
- Always keep this instruction manual ready at hand for quick reference, even after completing the assembly.
- Could cause serious injury or even death


SPECIFICATION

Wing Span: 2400mm (94.5in)
Wing Area: 106.7dm² (1654.5sq.in)
Total Length: 2165 mm (85 in)
Engine : 100cc gas engine
Radio : 6-7 channels , 11 servos


REQUIRED FOR OPERATION (Purchase separately)

- 1 A minimum 6-7 channel radio for airplanes (with 11servos).
And dry batteries.


 **CAUTION:** Only use a minimum 6-7channel radio for airplanes! (No other radio may be used!)



12 AA-size Batteries






receiver




remote control

For handling the radio properly, refer to its instruction manual.
- 2 Battery (need 2)
- 3 Servo(need 11servos)
- 4 Engine and Muffler
Model Airplane engine:100cc gas engine




- 5 Glue




Epoxy Glue




Instant glue
- 6 required for engine starting


 **WARNING:** Normal gasoline cannot be used with glow engines.





Fuel Pump




Plug Wrench




Glow engine fuel only.
- 7 Silicone Tube




- 8 Other equipment for enhancing airplane operation & performance




Engine Starter



12V Battery (for starter)
- 9 Purchase a propeller that will match your engine













TOOLS REQUIRED (Purchase separately)



BEFORE YOU BEGIN

- 1 . Read through the manual before you begin ,so you will have an overall idea of what to do.
- 2 . Check all parts .if you find any defective or missing parts .contact your local dealer.
- 3 Symbols used throughout this instruction manual,comprise.

 Apply epoxy glue.	 Drill holes with the specified Diameter(here:2mm)	 Must be purchased separately!	 Warning! Do not overlook this symbol.
 Apply instant glue (CA glue,super glue).	 Ensure smooth non-binding movement while assembling.	 Pay close attention here!	
 Assemble left and right Sides the same way.	 Cut off shaded portion.	 Cut off excess.	




Accessory list for this page.

2.5X85mm rod	Horn	-----6
3mm screw		-----6
	Rod adjuster	-----12
4X35mm screw		-----6
	Connecting rod head	-----6
3X10mm Screw		-----6
Hinge	2.3X10mm Tp screw	-----6
	3X14mm Screw	-----6
Hinge		-----6
		-----6
3mm Lock nut		

3

Install the aileron and flap




1

Install the elevator glue the hinges with Epoxy


Bottom view

L/R




4

Install the aileron and flap servo




2

Install the elevator servos



5






Accessory list for this page.

4X50mm screw	Horn
----- 2	----- 2
3X10mm Screw	----- 2
----- 2	Rod adjuster
3X14mm Screw	----- 4
----- 2	Connecting rod head
3mm Lock nut	----- 2
----- 2	----- 2
3mm screw	2.5X45mm rod
----- 2	----- 2
6mm Bind nut	6X125mm screw
----- 4	----- 4
Hinge	6mm Washer
----- 8	----- 4


8

Install the flap servo



6


Install a 5mm control spring in to both flap panel.



notice:double check and made sure both flap panel can be moving together by spring but will not jam before you glue the flap hinges


9

Main wing




7

Install the flap, Drill 4.5mm hole for flap hinges as show



10

Install M5 blind nut inside each wing mount block from inside the glue them with Epoxy







Accessory list for this page.

3X25mm screw	Rod adjuster
----- 1	----- 2
2X8mm screw	Connecting rod head
----- 2	----- 1
2.5X85mm rod	Hinge
----- 1	----- 2
4X25mm screw	4mm Washer
----- 2	----- 2

13 Install the rudder servo




11 Install the rudder




14 Install the elevator



12 Install the rudder servo



15 Main wing&Horizontal/Vertical tail





Accessory list for this page.

18 Install the main landing gear




you also need to glue two hinges in each side landing gear door.

16 Install the main landing gear



Mount the main gear in to the gear bay and fix it by six mount bolt as show.the wheel for this model are 4.5in or 115mm

19 Install the main landing gear



you also need to glue two hinges in each side landing gear door.

17 Install the main landing gear



if you plan to use lading gear door, you need to open four slot on the landing gear bay for the door hinges.





20 Install the tail wheel




Install the tail gear ang tail gear servo as show. Notice: this servo need minimum 3kg torque. Unless it can be fail to controll or damage.




Accessory list for this page.

Linkage Stopper 1.8X450mm Rod
 --- 1  ----- 1
 2mm Nut 3X3mm Screw
 --- 1  ----- 1

23 Install the throttle servo




21 Installing the engine




24 Assembly of the full tank


After confirming the position (see front of fuel tank). Insert and tighten the screw.



22 Installing the engine (100cc)




25 Radio Equipment






Accessory list for this page.

3X16mm screw

 ----- 6

3mm Washer


 ----- 6

3mm rubber band

 ----- 6

2.6X12mm Tp screw


 ----- 6

 Fasten ----- 3

28 Install the canopy


Cut away the surplus parts of canopy care fully along the shaded line.





 2.6X12mm Tp screw ----- 6

26 Install the thr cowling




3X16mm screw  ----- 6

3mm Washer  ----- 6

3mm rubber band  ----- 6

29 Install the cover



 Fasten ----- 3


27 Install the thr cowling

☒ Propeller

☒ Spinner




30 Install the cover




31 Adjustment.

Adjust the travel of each control surface to the values in the diagrams.
These values fit general flight capabilities.
Readjust according to your needs and flight level.




33 Adjustment

Adjust the travel of each control surface to the values in the diagrams.
These values fit general flight capabilities.
Readjust according to your needs and flight level.




32 Adjustment.

Adjust the travel of each control surface to the values in the diagrams.
These values fit general flight capabilities.
Readjust according to your needs and flight level.



34 Adjustment.

Never fly before checking the Cg' s required position.
In order to obtain the CG specified ,reposition the receiver and battery.



警告
Warning!

NEVER fly the model
without well balancing.