

# F8F Bearcat




#### Warning! SAFETY PRECAUTIONS This radio control model is not a toy!


- •First-time builders should seek advice from people having building experience in order to assemble the model correctly and to produce its performance to full extent.
- •Assemble this kit only in places out of children's reach!
- Take enough safety precautions prior to operating this model. You are responsible for this model's assembly and safe operation!
- •Always keep this instruction manual ready at hand for quick reference, even after completing the assembly.

#### SPECIFICATION

WingSpan	2460 mm (96.8in)
WingArea	96 dm²(1473sq.in)
Length	1930 mm (76 in )
Engine	80-100 cc gas engine
Radio	6 channel, 10 servos

### **REQUIRED FOR OPERATION (Purchase separately)**





## **BEFORE YOU BEGIN**

Read through the manual before you begin, so you will have an overall idea of what to do.

Drill holes with the specified


- Check all parts .if you find any defective or missing parts .contact your local deater.
  - Symbols used throughout this instruction manual, comprise.







Apply epoxy glue.




Assemble left and right Sides the same way.




2mm

Cut off shaded portion.

Diameter(here:2mm)



Must be purchased separately!



Do not overlook this symbol.



Cut off excess



Pay close attention here!





