

### Thank you for choosing CYmodel

Global: www.cymodel.com

# F8F Bearcat



### Instruction Manual

Before commencing assembly, please read these instructions thoroughly.




## Warning! SAFETY PRECAUTIONS This radio control model is not a toy!

- First-time builders should seek advice from people having building experience in order to assemble the model correctly and to produce its performance to full extent.
- Assemble this kit only in places out of children's reach!
- Take enough safety precautions prior to operating this model. You are responsible for this model's assembly and safe operation!
- •Always keep this instruction manual ready at hand for quick reference, even after completing the assembly.
- •Could cause serious injury or even death

#### **SPECIFICATION**

Wing Span2135 mm (84 in)
Wing Area72 dm²(1120 sq.in)
Take-off weight10.4 kg
Length1680 mm (66.1in)
Engine35-50cc gas engine
Radio6 channels, 10 servos


#### REQUIRED FOR OPERATION (Purchase separately)






12 AA-size Batteries

For handing the radio properly refer to its instruction manual.





Propeller splinner












### **TOOLS REQUIRED (Purchase separately)**



#### **BEFORE YOU BEGIN**

- Read through the manual before you begin, so you will have an overall idea of what to do.
- . Check all parts .if you find any defective or missing parts .contact your local deater.
- . Symbols used throughout this instruction manual, comprise.



Apply epoxy glue.



Drill holes with the specified Diameter(here:2mm)



Must be purchased separately!



Apply instant glue Ensure smooth non-binding movement while assembling. (CA glue, super glue).



Pay close attention here!

Do not overlook this symbol.

Assemble left and right Sides the same way.




Cut off shaded portion.




Cut off excess.







#### 3 Epoxy flap hings to trailing edge




### Epoxy pin hings to aileron steadily




#### 4 Install the servo




### 2 Install the aileron




### Install the nylon control horn and connect the linkage









### 8 Install the main landing gear




### Install the nylon control horn and connect the linkage




#### 9 Install the main wing




### 7 Install the main landing gear




### 1 ) Epoxy pin hings to elevator









#### 13 Install the horizontal tail




### 11 Epoxy pin hings to elevator




### 1 4 Assemble horizontal tail




### 12 Install the nylon control horn and connect the linkage




#### 15 Install the horizontal tail









### 18 Install the tail wheel




### Rudder . Connect the linkage rod to the horn




### 19 Install the tail wheel




### 1 7 Epoxy the rudder to the vertical tail edge.




### 20 Install the tail wheel









#### 23 Mount elevator servo into the fuselage




#### 21 Fitting of the tail wheel assembly




#### 24 Mount cowling on the fuselage




### 22 Assemble the plate to the fuselage




### 25 Installation the engine









### 28 Install the guided missile



### 26 Assembly of the full tank



### 29 Install the adorning



### Mount the fuel into the fuselage




### 30 Mount canopy on the fuselage



### 31 Adjustment.

Adjust the travel of each control surface to the values in the diagrams.

These values fit general flight capabilities. Readjust according to your needs and flight level.




### 33 Adjustment.

Adjust the travel of each control surface to the values in the diagrams.
These values fit general flight capabilities.
Readjust according to your needs and flight level.

Side view

### 32 Adjustment.



### 34 Centre of Gravity.

