

AT-6 TEXAN



0.91-1.10 cu. in. displacement 4-stroke

Requires: 6-channel radio w/ 6 standard servos

Specifications

Wing Span 72 in / 1830 mm

Wing Area 777 sq in / 50.1 sq dm

Flying Weight 8.4 lbs / 3800 g

Fuselage Length 51.5 in / 1310 mm

Warning! This model is not a toy.

It is designed for maximum performance. Please seek advice if one is not familiar with this kind of engine powered precision model. Operating this model without prior preparation may cause injuries. Remember, safety is the most important thing. Always keep this instruction manual at hand for quick reference.



FACTORY PRE-FABRICATED ALMOST-READY-TO-FLY(ARF) SERIES MADE IN CHINA

^{*} Specifications are subject to change without notice.*

AT-6 TEXAN

INDEX—

BEFORE YOU BEGIN	P. 1
PARTS LIST	P. 2
ASSEMBLY	P. 3 -12
SAFETY PRECAUTIONS	P.13

BEFORE YOU BEGIN

- Read through the manual before you begin, so you will have an overall idea of what to do.
- Check all parts. If you find any defective or missing parts contact your local dealer. Please DRY FIT and check for defects for all parts that will require CA or Epoxy for final assembly. Any parts you find to be defective after the gluing process may be difficult to remove for warranty replacement. The manufacturer will replace any defective parts, but will not extend to the parts that are good before gluing to defective parts during assembly. Warranty will not cover any parts modified by customer.
- 3 Symbols used throughout this instruction manual comprise of the following : -
 - AB Apply epoxy glue. C.A
- C.A Apply instant glue (C.A.glue, super glue.)
 - Apply thread locker N.I. Must be purchased separately!
 - Assemble left and right sides the same way.

 Ensure smooth non-binding movement while assembling.
 - Peel off shaded portion covering film.

 Cut off shaded portion.
 - Drill holes with the specified diameter (here: 3mm).


 Pierce the shaded portion covering film.
 - Pay close attention here! Warning! Do not overlook this symbol!




Parts List

- 1. MAIN WING -- 1 set
- 2. RETRACTABLE LANDING GEAR LG4404502 -- 1 pair RETRACTABLE LANDING GEAR COVER -- 1 pair SCREW PM2x8mm -- 8 pcs M2 NUT -- 8 pcs WASHER d2xD5mm -- 16 pcs 180mm Y-CORD Kw0021800 - 1 pc.
- 3. SCREW PB2x25mm -- 6 pcs SCREW PWA2x8mm -- 8 pcs PUSHROD Ø1. 8x85mm w/ Threads (For Aileron Servos) -- 2 pcs TRI-HORN M3x14mm (L) (For Aileron) PL4111185 -- 2 sets SERVO MOUNTING PANEL 2mm (For Aileron Servos) -- 1 pair CLEVIS PL4112103 -- 2 pcs STRAPER PL4112102 -- 2 pcs FUEL TUBE Ø6x5mm -- 4 pcs
- 4. WIRE Ø1.8x75mm (For Flxing flap) -- 2 pcs
- 5. SCREW PB2x15mm -- 3 pcs PUSHROD Ø1.8X100mm w/ Threads (For Flap Servo) -- 1 pc. TRI-HORN M3x14mm (L) (For Flap) PL4111185 -- 1 set CLEVIS PL4112103 -- 1 pc. STRAPER PL4112102 -- 1 pc. FUEL TUBE Ø6x5mm -- 2 pcs
- 6. STABILIZER & ELEVATOR -- 1 set FUSELAGE -- 1 pc.
- 7. VERTICAL FIN & RUDDER -- 1 set
- 8. TAIL LANDING GEAR PL7100002 -- 1 set SCREW PA3x12mm -- 2 pcs COLLAR 2.6mm w/set screw -- 1 set TAIL WHEEL Ø30mm-- 1 pc.
- 9. SCREW PB2x22mm -- 6 pcs PUSHROD Ø1.8x730mm w/ Threads (For Elevator Servo) -- 2 pcs TRI-HORN M3x22mm (L) (For Elevator Servo) PL4111251 -- 2 sets CLEVIS PL4112103 -- 2 pcs FUEL TUBE Ø6x5mm -- 2 pcs
- 10. SCREW PM2.5x35mm -- 3 pcs PUSHROD Ø1.8x835mm w/ Threads (For Rudder Servo) -- 1 pc. TRI-HORN M3x22mm (L) (For Rudder Servo) PL4111251 -- 1 set CLEVIS PL4112103 -- 1 pc. FUEL TUBE 6x5mm -- 1 pc.

- 11. FUEL TANK 400cc PL1111400N -- 1 set CABLE TIE (For Fuel Tank) 1.5x5x400mm -- 1 pc. DOUBLE-SIDED TAPE 40x100mm -- 1 pc.
- 12. SOCKET HEAD SCREW M4x25mm-- 4 pcs WASHER d4xD12mm -- 4 pcs BLIND NUD M4x15mm -- 4 pcs ENGINE MOUNT PL5111080 -- 1 set
- 13. LINKAGE CONNECTOR 2.1mm HW7111060 -- 1 set
- 14. THROTTLE PUSHWIRE Ø1. 2x400mm -- 1 pc.
 PLASTIC TUBE d2xD3x200mm -- 1 pc.
 ENGINE MOUNT ALUMINUM PLATE -- 1 set
 ANTI-VIBRATION MOUNT 4C-91 PL5214094 -- 1 set.
 INCLUDE: SOCKET HEAD SCREW M4x35mm -- 4 pcs
 SCREW KM3x20mm -- 8 pcs
 WASHER d4xD12mm -- 8 pcs
 NYLON INSERT LOCK NUT M3 -- 8 pcs
 NYLON INSERT LOCK NUT M4 -- 4 pcs
- 15. FUEL TUBE Ø6x5mm -- 2 pcs STRAPER PL4112102 -- 2 pcs SPONGE 10x80x200mm -- 2 pcs PUSH ROD Ø1.8x75mm (For Elevator) -- 1 pc. PUSH ROD CONNECTOR (For Elevator) PL4410010 -- 1 set
- 16. SOCKET HEAD SCREW M4x55mm -- 2 pcs WASHER d4xD15mm -- 2 pcs PLYWOOD 2x25x100mm (Wing Protection) -- 1 pc.
- 17. SCREW PWA2.3x8mm -- 6 pcs SILICON GROMMET d1.5xD6.5mm -- 6 pcs PILOT PC001085A -- 1 set CANOPY --1 pc.
- 18. SCREW PWA2.6x12mm -- 8 pcs
 COWLING -- 1 pc.
 TRANSPARENT 3D TEMPLATE -- 1 pc.
 COWLING BRACKET PL5320010 -- 4 pcs
 QUICK RELEASE NYLON RIVET PL1208042 -- 4 pcs
 SCREW KA2.3x8mm -- 4 pcs
 SPINNER NUT HW2340001 -- 1 set
 CARB INTAKE -- 1 set
 OIL COOLER INTAKE -- 1 set
- 19. DECALS: A212DEC -- 1 set
- COVERING:- TOUGHLON STL 201 BLACK
 TOUGHLON STL 331 CUB YELLOW








P.3




Ø1mm pilot holes for World Models tri-horn are pre-drilled.
 Please look for pin-hole marks at under side of control surfaces.











4 Main Wing


Apply glue to both sides of all surfaces in contact. Use a stick to apply glue to inner side of wing joiner sleeve, and apply glue to wing joiner before putting them together. Wing joiner not glued properly will lead to wing failure and plane crash.








L/R






























14 Engine





M3 Nylon Insert Lock Nut
















• Please refer to the attached sheet for usage of the transparent 3D template.











19 Wing Setting

• Adjust the wing and fuselage configuration as shown in the diagrams.








A = A' B = B' C = C'

A212PO31011512 P.11

20 Control Throws

Adjust the control throws as shown in the diagram. These throws are good for general flying. You can adjust according to your personal preference.



21 C.G.

The ideal C. G. position is 135 mm (5.3 in) behind the leading edge measured at where the wing meets the fuselage. In order to obtain the C. G. specified, add weight to the fuselage or move the battery position. Check the C. G. before flying.

If you are converting this model to electric, please move the C.G. forward 10% of current C.G. distance from leading edge to compensate for weight of fuel.



Measure C.G. with the wheels in retracted position


http://www.theworldmodels.com/para/instruction/instructionManuals.php



Important Safety Precautions

- # First time flyer should never fly by himself / herself. Assistance from experienced flyer is absolutely necessary.
- # Pre flight adjustment must be done before flying, it is very dangerous to fly a badly pre adjusted aircraft.
- # AT-6 TEXAN is specially designed to be powered by 0.91-1.10 4-stroke glow engine, using a more powerful engine does not mean better performance. In fact, over powered engine may cause severe damage and injuries.
- # Make sure the air field is spacious, never fly the plane too close to people and never get too close to a running propeller.
- # If you find wrinkles on the covering as a result of weather changes, you can use hot iron to remove the wrinkles. Please begin with lower temperature setting and gradually raise the temperature until the wrinkles are gone. Too hot an iron may damage the covering. Don't use hot iron near the seams or edges, hot iron will melt the glue and shrink the covering at the same time, causing the seams to pull away.
- # Check and re-tighten up all factory assembled screws, use thread locker if necessary.
- # When Flaps are lowered, nose of model will rise. The nose-up varies with the speed at which the models is flying when you lower the flaps and the extent to which they are lowered. Check effect of flaps at higher altitude to avoid surprises during landing. You may apply down trim of the elevator to compensate for the nose-up effect when lowering the flaps. Taking off with flaps lowered is not recommended, as the increased drag may require a longer runway and more engine power for the model to take off.

Should you require to bend the landing gear wire, please insert a round metal bar into the spring ring and apply force there as leverage. Bending the wire directly may damage the mounting block structure.




P.13


Usage of the transparent 3D template




This transparent 3D template is used for position guidance of the actual cutting of the pre-painted cowling.










Simply cut the transparent 3D template to fit your engine and exhaust pipe, then slide onto the actual cowling and use as template to mark the openings required for final cutting.



Ducted Fan

Pattern

Warbirds

Funfly

Scale

Electric

Sports

Glider

Trainer

Boat

Accessories

Covering

(Lightex / Toughlon)

